

QUICK START GUIDE




MENU

Getting Started	1
Button Functions	2
Soft/Virtual Keys	3
Opening the Phone Cover	4
Inserting the Battery	5
Inserting a SIM Card	6
Inserting an SD Card	7
Charging Your Device	8
Performing a System Update	9
Performing a Memory Clean Up	12
My phone has no service. What do I do?	13
Phone Specifications	14



GETTING STARTED





BUTTON FUNCTIONS

Power Button

When phone is turned off:

Press and hold the power button to turn on

When phone is turned on:

- Press the power button to turn the screen on or off
- Press and hold to trigger the menu selection for "Power off", "Reboot" and "Airplane mode"
- Press and hold for more than 13 seconds to force power off
- Press to mute during incoming call ring

Volume Button

- Press button to tune volume up and down
- Press to mute during incoming call ring
- Press volume button down + power button to take screenshot.



SOFT / VIRTUAL KEYS



MENU KEY

HOME KEY

RECENT TASK KEY

BACK KEY

Menu Key

Press to show setting menu

Recent Task Key

Press to show running applications

Home Key

Press to go back to the home screen, press and hold while sliding up will launch Google Now

Back Key

Press this button to back to previous screen




OPENING THE PHONE COVER





INSERTING THE BATTERY






INSERTING A SIM CARD






INSERTING AN SD CARD





CHARGING YOUR DEVICE






PERFORMING A SYSTEM UPDATE




- 1. Turn on the phone.
- 2. Use the system updates app to check new version.
- 3. You can also use (Settings > About phone > System > Updates > Click on Check new version)




PERFORMING A SYSTEM UPDATE



1. If there is a new version, the info will be displayed under Update Information.




2. Click Download and it will proceed.




3. Once the download has completed, select INSTALL. The phone will auto reboot.



PERFORMING A SYSTEM UPDATE




4. After the reboot, the Notification bar will show Update successful



5. You can go to Settings > About Phone > Device Information to check the build number.



PERFORMING A MEMORY CLEAN UP



- 1. Press the Recent Task key from any screen.
- 2. Tap the duster icon to clean the memory.



MY PHONE HAS NO SERVICE. WHAT DO I DO?



Press and hold the power button to reboot the phone.



PHONE SPECIFICATIONS

Chipset	Qualcomm MSM8916
CPU	Quad core 1.0 GHz
os	Android 5.1
Dimension	142*72*8.7mm
Display	5" HD IPS On-Cell Display
Camera	8MP F/2.0 rear + 2MP front camera
Memory	1GB RAM + 8GB ROM
Port	Micro USB
External Storage	Micro SD card up to 32GB
Battery Capacity	2300mAh
SIM card/type	Dual SIM (Micro SIM)
Ear Phone	3.5mm CTIA

EVERY SHADE FOR EVERY STYLE









YES CARE

Email us at **yescare@yes.my**Call us at **018 333 0000**

For more information, visit

www.yes.my/altitude